

INSTALLATION AND SPECIFICATIONS FOR SMART SET PEDESTRIAN SYSTEM

WARNING: The Smart Set Pedestrian rail system using the weighted base attached to the smart post for free standing is NOT designed and can NOT be used for fall protection.

(MOUNTING CENTERS FOR THE PEDESTRIAN RAIL SYSTEM)

We recommend setting post up on 8 ft centers using 10 ft rails overlapping each post by 1 ft each direction for best stability.

(HAND TIGHTEN) thumb screw to lock the rails in place.

(PEDESTRIAN OR CORAL SYSTEM OPTIONS) Set post with weighted base on desired centers then slide plastic, vinyl or wood rails into post letting them run past each post by 1 ft then hand tighten thumb screws on the post to lock the rail in place. When coming to a corner set up post 2 ft away from the corner and let the rail run by until it contacts the railing coming from the other direction

(ATTACHING WEIGHTED RUBBER BASE TO SMART POST FOR FREE STANDING PEDESTRIAN RAIL, CORAL OR WARNING LINE SET UP)

(a) When mounting weighted base to the Smart Post turn the post upside down balancing it on the handle and set the rubber base on the base of the post while aligning the 4 holes.

(b) Place the 4 nylon washers in the recessed holes in the rubber base.

(c) Start the 4 nylon screws threading them in by hand until snug.

(d) To tighten the bolts use a socket or a large standard screw driver.

Warning! DO NOT OVER TIGHTEN PLASTIC SCREWS.

Please refer to the www.smartsetsafety.com website for more information.

Questions concerning installation, Contact your Smart Set Safety Distributer.